



Some users have been asking how to disable the Frontview illuminated front panel on the Antec Fusion HTPC case and Multimedia Station. Here's how to disable and control the FrontView:

1. **First, make sure that the iMON software is properly installed on your PC.** This is the only way to control the FrontView display on your Fusion case. You can install the iMON software with the disc that came with your Fusion case, or download the software from the Soundgraph site at <http://www.soundgraph.com>.
2. **Once the iMON software is running, right click on the dial and select "iMON Manager".** This will cause the iMon Manager to open.



3. **From the iMon Manager, select "iMon Utilities", then "FrontView" from the list of options on the left-hand side.** You should see this:



4. **From the FrontView pane of the iMon Manager, turn off and manage FrontView settings.** On this selection panel, there are several options for disabling or controlling the Frontview screen.



- a. **To enable Frontview during normal operation but shut it off during video playback**, check the "Turn Off FrontView During Video Playback" box.
  - b. **To enable FrontView only during certain hours** (for instance, only at night), select "Enable" on the "Scheduled On/Off" option. Entered the on and off times you wish to schedule.
5. **Select "OK" at the bottom of the window to save your selections.**