



- ① LED signal connector
 - ② Connect it with the LED I/O port connector
 - ③ ~ ⑧ ARGB signal connectors
 - ⑨ PSU SATA connector
 - ⑩ Connect it with the motherboard sync connector
-
- ① LED燈條接口
 - ② 連接I/O上LED控制鈕接口
 - ③ ~ ⑧ ARGB訊號接口
 - ⑨ 電源SATA接口
 - ⑩ 連接主機板訊號線

• Instructions for inbuilt controller 內建控制板說明:

1. Make sure ①、②、⑨、⑩ are well connected.
先確認 ①、②、⑨、⑩ 端子位置皆連接正確
2. Connect the fan ARGB signal connectors with ③ ~ ⑧
將ARGB風扇訊號線安裝 ③ ~ ⑧ 位置
3. Connect SATA connector with ⑨
連接 ⑨ SATA電源
4. Press the Power button on the case.
開啟機箱Power按鍵
5. Press the LED mode button on the I/O port, enjoy more than 13 light effects.
操作I/O上LED控制按鍵,共13種燈效模式

• If you would like it to work in sync with the motherboard, please connect ⑩, the 3-pin connector with the motherboard.

如需與主板ARGB同步操作·請將 ⑩ 3pin接線連接至主機板

1. Long press the LED button for 3-6 seconds and wait for white light blinking twice, and it will change to motherboard sync mode.
長按I/O上LED控制按鍵3~6秒·待連續兩次白光閃爍時·將會切換至與主板同步模式。
2. If you would like to use the LED button on the I/O port, long press it for 3-6 seconds, and it will return to the inbuilt controller mode.
如欲切回機殼內建燈光控制板·請至I/O上LED控制按鍵長按3~6秒·待連續兩次白光閃爍時·將會切換回機殼內建燈光控制板燈效模式。
3. If you press the LED button for more than 6 seconds, the light effects will be turned off after the white light blinks 4 times. Press the LED button again, and it will return to the inbuilt controller mode.
如長按I/O上LED控制按鍵大於6秒,LED將會在4次白光閃爍後自動關閉燈光·再按一次I/O上LED控制按鍵則恢復內建燈光模式。